This drawing is furnished for preliminary design purposes only, and should not be used for final design drawings or construction drawings without the certification of a professional engineer registered in the state in which the wall will be constructed Place geogrid in next 8" layer of left by previous layer of geogrid. block in a manner to reinforce gaps Monument HD® **Geogrid Details** <u>Z</u> 0. Concave curve overlapped geogrid (Typ.) Min. 3" of soil between Date. Place geogrid in next layer of block with the main reinforcement direction below. Place within curve only. running 90° to the previous Convex curve RETAINING WALLS A better way Additional geogrid overlap extend wall height / 4 4" Crushed ine eling pad Geogrid Outside corner Inside corner Geogrid Details 90° to the previous direction below. Place geogrid in next layer of block with the main reinforcement running **⋨** 爻 MM/DD/YYYY Number: WWWPRO# 약